


EXTERNAL REGULATOR
TB - L




TB-L
UNIVERSAL
(1/4 WIDE TERMINALS)

(110) BLACK — E [F2 - NEG. FIELD]
(84) GREEN — F [F1 - POS. FIELD]
EXTERNAL REGULATOR,
"B" CIRCUIT
"NO CHARGE" LIGHT NOT USED.

TB-L
WHEN USED ON CHRYSLER OR
OTHER ALTERNATORS WITH;
ONE BRUSH GROUNDED,
USE GREEN WIRE ONLY.
— OR —
BOTH BRUSHES INSULATED,
USE BOTH WIRES.

WIDE TERMINALS, EXTERNAL REG.
TB - LW




TB-LW
UNIVERSAL
(3/8 WIDE TERMINALS)

(110) BLACK — E [F2 - NEG. FIELD]
(84) GREEN — F [F1 - POS. FIELD]
EXTERNAL REGULATOR,
"B" CIRCUIT
"NO CHARGE" LIGHT NOT USED.

TB-LW
WHEN USED ON CHRYSLER OR
OTHER ALTERNATORS WITH;
ONE BRUSH GROUNDED,
USE GREEN WIRE ONLY.
— OR —
BOTH BRUSHES INSULATED,
USE BOTH WIRES.

THREADED POST TERMINALS, EXT. REG.
TB - 68





TB-68
UNIVERSAL
(#27 CLIPS)

(110) BLACK — E [F2 - NEG. FIELD]
(84) GREEN — F [F1 - POS. FIELD]
EXTERNAL REGULATOR,
"B" CIRCUIT
"NO CHARGE" LIGHT NOT USED.

12/94 **TB-68**
WHEN USED ON CHRYSLER OR
OTHER ALTERNATORS WITH;
ONE BRUSH GROUNDED,
USE GREEN WIRE ONLY.
— OR —
BOTH BRUSHES INSULATED,
USE BOTH WIRES.

NARROW TERMINALS, EXTERNAL REG,
TB - LN
CHRYSLER COMPUTER CONTROLLED ALTERNATORS



TB-LN
UNIVERSAL
(NARROW TERMINALS)


(110) BLACK — E [F2 - NEG. FIELD]
(84) GREEN — F [F1 - POS. FIELD]
EXTERNAL REGULATOR,
"B" CIRCUIT
"NO CHARGE" LIGHT NOT USED.

3/03 **TB-LN**
WHEN USED ON CHRYSLER OR
OTHER ALTERNATORS WITH;
ONE BRUSH GROUNDED,
USE GREEN WIRE ONLY.
— OR —
BOTH BRUSHES INSULATED,
USE BOTH WIRES.

TBTLCH.DRW 04-98

EXTERNAL REGULATOR TB - LC


LATE MODEL CHRYSLER COMPUTER CONTROLLED ALTERNATORS WITH "F" & "SENSE/+" TERMINALS



<p>TB-LC USED ON LATE MODEL CHRYSLER ALTERNATORS WITH ONE BRUSH INTERNALLY GROUNDED</p> <p>GREEN 84 (F1)</p> <p>YELLOW 108 (SENSE)</p> <p>DO NOT SWAP LEADS</p>	<p>4/09 TB-LC USED ON LATE MODEL CHRYSLER ALTERNATORS WITH ONE BRUSH INTERNALLY GROUNDED</p> <p>EXTERNAL REGULATOR, AUX VOLTMETER = APPROX. 2 V. LESS THAN OUTPUT VOLTS</p> <p>"NO CHARGE" LIGHT NOT USED.</p>
--	---

EXTERNAL REGULATOR TB - 362/363/377

COMBINATION LATE MODEL CHRYSLER COMPUTER CONTROLLED ALTERNATORS WITH "F" & "F" (plug code 362/363) AND "F" & "SENSE/+" TERMINALS (plug code 377)



<p>08/18 TB-362/363/377</p> <p>(F1)(F2) (F1)(F2) (F1)(S) P.C. 362 P.C. 363 P.C. 377</p> <p>EXTERNAL REGULATOR, TEST BENCH "NO CHARGE" LIGHT NOT USED.</p>	<p>TB-362/363/377 EXTERNAL REGULATOR, "B" CIRCUIT</p> <p>AUX V. NOT USED ON 362/363 AUX V. = OUTPUT V. ON 377</p> <p>REPLACES TB-LN and TB-LC</p>
--	---

TBTLCH.DRW 02-10 R-1 09-16